



DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS



DOUBLE DOOR WALL LOCKER (DDWL)


INSTALL INSTRUCTIONS



DOUBLE DOOR WALL LOCKER (DDWL)


INSTALL INSTRUCTIONS

TOOLS NEEDED




RUBBER
MALLET


or




PLASTIC
TIP HAMMER




QUICK GRIP
CLAMPS




POWER
DRILL



PHILLIPS #2
SCREWDRIVER




COMMON
SCREWDRIVER



SOCKET WRENCH




3/8" & 7/16"
SOCKET





3/8" & 7/16"
WRENCH


INCLUDED HARDWARE




#1/4-20 X 3/4"
PAN HEAD PHILLIPS
MACHINE SCREW (4)
PSCR0091



1/4-20
NYLON LOCK NUT(4)
PNUT0011



N8 x .375 TEK SCREW (20)
PSCR0016



#10-24 X 5/8"
PAN HEAD PHILLIPS
MACHINE SCREW (4)
PSCR0041




10-24
NYLON LOCK NUT(4)
PNUT0055


DOUBLE DOOR WALL LOCKER (DDWL) INSTALL INSTRUCTIONS

COMPONENTS


"L" UPRIGHT QTY. (2)




"T" UPRIGHT QTY. (1)




BACK PANEL QTY. (1)




TOP PANEL QTY. (1)




TOP PANEL SUPPORT QTY. (2)




FRONT SHELF SUPPORT QTY. (2)




TOP PANEL
LOCKING BRACKET QTY. (4)




PUNCHED SHELF QTY. (2)




BACK SHELF SUPPORT QTY. (2)




SIDE SHELF QTY. (3)



BOTTOM SUPPORT QTY. (2)




SIDE SHELF
SUPPORT QTY. (6)




DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS


COMPONENTS




DOOR ASSEMBLY (HD2)



DOOR ASSEMBLY SHOWN
OPEN



DRAWER ASSEMBLY (SD)




GARMENT ROD ASSEMBLY
(GT & GB)

DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS

STEP: 1

IF NOT ALREADY INSTALLED, INSTALL THE LEVELING GLIDE KNOCK-IN MOUNTS (QTY. 4) IN THE BOTTOM (END WITH FLANGE) OF THE "L" UPRIGHTS AS SHOWN IN FIGURE A, DETAIL B. INSTALL LEVELING GLIDES IN KNOCK-IN MOUNTS LEAVING 1/8" CLEARENCE BETWEEN LEVELING MOUNT, AND INSIDE SURFACE (HEX SHAPE) OF LEVELING GLIDE.




DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS

STEP:2

ASSEMBLE THE FRONT OF THE LOCKER USING QTY. (2) "L" UPRIGHT ASSEMBLIES, AND QTY. (3) SUPPORTS IN POSITIONS AS SHOWN IN FIGURE C. INSTALL POSITION RETAINING SCREWS (#8 X .375 TEK SCREWS) QTY. (2) PER, IN BOTTOM , AND QTY (2) FRONT SHELF SUPPORTS, AS SHOWN IN DETAILS D AND E.

FIGURE C




DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS

STEP:3

WITH LOCKER LAYING ON ITS BACK, POSITION THE REAR BACK PANEL SO AS THE FLANGES ARE AGAINST THE KEYHOLE FACE OF THE UPRIGHT AS SHOWN IN FIGURE F, DETAIL G AND H. PANEL SHOULD BE JUST SHORT OF FLUSH WITH BOTTOM AND TOP OF UPRIGHT ASSEMBLIES.

FIGURE F




DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS

STEP:4

INSTALL REAR SHELF SUPPORTS SANDWICHING THE REAR PANEL BETWEEN THE SHELF SUPPORTS AND KEYHOLE SLOT FACE OF THE UPRIGHT. INSTALL THE POSITION LOCK SCREWS IN THE SUPPORTS SAME AS STEP 2, MAKING SURE TO KEEP THE BACK PANEL FLUSH WITH THE TOP AND BOTTOM OF THE "L" UPRIGHTS AS SHOWN IN FIGURE J, DETAILS K,L AND M.

FIGURE J




DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS

STEP:5

STAND UNIT UPRIGHT, INSTALL DRAWER SUSPENSION MOUNTING (LEFT AND RIGHT) AS SHOWN IN FIGURE N, DETAIL O. REFER TO 4POST DRAWER (SD) INSTALLATION INSTRUCTIONS, STEPS 1 THRU 3.


FIGURE N



DETAIL O


DOUBLE DOOR WALL LOCKER (DDWL) INSTALL INSTRUCTIONS

FIGURE P



STEP:6

TEMPORARILY INSTALL UPPER AND LOWER SHELF, THIS WILL HELP TO SQUARE UP UNIT. INSTALL FRONT AND REAR TOP COVER SUPPORTS.





STEP: 7

ASSEMBLE DOOR FRAME TO FRONT OF UNIT STARTING AT THE TOP AND WORKING DOWN (DETAIL Q). REFER TO 4POST HINGED DOORS (HD2) ASSEMBLY INSTRUCTIONS, STARTING WITH STEP 6 AND WORKING BACKWARD TO STEP 1.


STEP: 8

REMOVE SHELVES, ATTACH DOOR FRAME BRACKETS TO SHELF SUPPORTS (DETAIL R). REFER TO 4POST HINGED DOORS (HD2) ASSEMBLY INSTRUCTIONS STEP 8.



DOUBLE DOOR WALL LOCKER (DDWL) INSTALL INSTRUCTIONS

FIGURE 5



DETAIL U

GARMENT RACK ASSEMBLY

SIDE UPRIGHT

CENTER UPRIGHT

SIDE SHELF SUPPORTS QTY. (6)

LOWER SHELF

GARMENT RACK ASSEMBLY


STEP:9

INSTALL LOWER SHELF, PLACE CENTER UPRIGHT INTO APPROXIMATE POSITION.

STEP:10

INSTALL SIDE SHELF SUPPORTS BETWEEN SIDE UPRIGHT AND CENTER UPRIGHT. THIS WILL LOCATE THE CENTER UPRIGHT OVER THE PROPER MOUNTING HOLES IN THE LOWER SHELF. INSTALL QTY (2) #10-24 x 5/8 MACHINE SCREWS THROUGH FLANGE OF UPRIGHT AND HOLES IN BOTTOM SHELF, SECURE WITH QTY (2) #10-24 NYLON LOCKNUTS, SEE DETAIL T.

#10-24 x 5/8
PAN HD. MACHINE SCREW
ATTACH W/ #10-24
NYLON LOCKNUT (2 PLACES)



DETAIL T

DOUBLE DOOR WALL LOCKER (DDWL)

INSTALL INSTRUCTIONS


FIGURE V

STEP:12

INSTALL TOP SHELF, SECURE TO CENTER UPRIGHT USING QTY (2) #10-24 x 5/8" MACHINE SCREWS AND 10-24 NYLON LOCKNUTS, SEE DETAIL W, INSTALL SIDE SHELVES.

STEP:13

INSTALL TOP PANEL LOCKING BRACKETS QTY (4), SECURE WITH POSITION LOCKING SCREW N8 x 3/8" TEK (4 PLACES), SEE DETAIL X.



DOUBLE DOOR WALL LOCKER (DDWL)


INSTALL INSTRUCTIONS

FIGURE Y

STEP:14

INSTALL TOP PANEL, FIRST REMOVE KNOCK-OUTS IN EACH CORNER OF PANEL, INSERT QTY. (4) 1/4 -20 x 3/4" MACHINE SCREWS THRU TOP PANEL AND TOP PANEL LOCKING BRACKETS, SECURE WITH QTY. (4) 1/4-20 NYLON LOCKNUTS, DRAW NUTS TO SNUG ONLY, DO NOT OVER TIGHTEN AND BEND TOP COVER. SEE DETAIL Z.

1/4-20 x 3/4"
PAN HD. MACHINE SCREW
ATTACH W/ 1/4-20
NYLON LOCKNUT (4 PLACES)



TOP PANEL


DETAIL Z

STEP:14

INSTALL BOTTOM DRAWER, REFER TO 4POST DRAWER (SD) ASSEMBLY INSTRUCTIONS STEP 4 AND 5.

STEP:15


INSTALL DOOR ASSEMBLYS, REFER TO 4POST HINGED DOOR INSTRUCTIONS (HD2) STEP 7.




END OF INSTRUCTIONS:

IF YOU NEED ASSEMBLY ASSISTANCE, PLEASE CONTACT CUSTOMER SERVICE AT
1-866-217-0330 (MONDAY THROUGH FRIDAY 8:00 AM - 5:00 PM E.S.T.)


4POST DRAWER (SD) INSTALLATION INSTRUCTIONS




TOOLS REQUIRED FOR ASSEMBLY




POWER
DRILL




PHILLIPS
SCREWDRIVER



FLAT HEAD
SCREWDRIVER



RUBBER
Mallet




or
PLASTIC
TIP HAMMER

INCLUDED HARDWARE



#10-24 x 3/8" Type '23'
Phillips Pan Head
Self-Threading Screw



#10-24 x 1/2" Type 'F'
Phillips Pan Head
Self-Threading Screw

- READ ALL INSTRUCTIONS BEFORE STARTING ASSEMBLY
- OPEN ALL BOXES AND MAKE SURE THAT YOU HAVE ALL REQUIRED COMPONENTS
- 4POST UNIT MUST BE PROPERLY LEVEL AND SQUARE PRIOR TO INSTALLATION OF DRAWERS





4POST DRAWER (SD) INSTALLATION INSTRUCTIONS

STEP 1:

LOCATE A MATCHING PAIR OF INNER BRACKETS AND (2) MATCHING PAIRS OF OUTER BRACKETS AS SHOWN IN FIGURE A. SLIDE THE OUTER BRACKETS INTO THE FLANGES OF THE INNER BRACKETS SO THAT YOU HAVE A MATCHING PAIR OF BRACKET ASSEMBLIES AS SHOWN IN FIGURE B. DO NOT SECURE INNER AND OUTER BRACKETS TO EACH OTHER AT THIS POINT.

STEP 2:

INSTALL DRAWERS FROM THE BOTTOM OF THE UNIT UPWARDS. POSITION ONE BRACKET ASSEMBLY INTO THE LOWEST OPEN KEYHOLE AS SHOWN IN FIGURE C. ONCE THE ASSEMBLY IS PROPERLY POSITIONED IN THE UPRIGHT, GENTLY TAP THE TOP OF THE BRACKET ASSEMBLY WITH A RUBBER Mallet TO PROPERLY SEAT IT IN THE KEYHOLES. REPEAT THIS STEP FOR THE BRACKET ASSEMBLY ON THE OPPOSITE SIDE OF THE FIRST DRAWER.



STEP 3:

WITH BOTH BRACKET ASSEMBLIES IN PLACE FOR THE FIRST DRAWER, SECURE BOTH INNER BRACKETS TO THEIR CORRESPONDING OUTER BRACKETS USING (4) #10-24 x 1/2" TAPPING SCREWS AS SHOWN IN FIGURE D. TO ENSURE THAT BRACKET ASSEMBLIES DON'T UNSEAT FROM KEYHOLES, INSERT A #10-24 x 3/8" TAPPING SCREW INTO THE UPPER HOLE OF EACH OF THE (4) OUTER BRACKETS AS SHOWN IN FIGURE D.

4POST DRAWER (SD) INSTALLATION INSTRUCTIONS

FIGURE F






FIGURE I




4POST DRAWER (SD) INSTALLATION INSTRUCTIONS

FIGURE K



DETAIL L



USE SECOND KEYHOLE
COMPLETELY ABOVE
DRAWER

STEP 6:

REPEAT STEPS 1-5 FOR ALL OTHER DRAWERS WORKING UPWARDS IN THE UNIT. USE THE SECOND OPEN KEYHOLE ABOVE THE PREVIOUS DRAWER TO MOUNT THE NEXT SET OF BRACKET ASSEMBLIES AS SHOWN IN FIGURE K AND DETAIL L.

STEP 7:

USE DRAWER CONVERSION / REINFORCEMENT PANEL APPROXIMATELY EVERY 36" OF HEIGHT AS SHOWN IN FIGURE M

END OF INSTRUCTIONS:

FOR ASSEMBLY ASSISTANCE CONTACT CUSTOMER SERVICE AT 1-866-217-0330 (MONDAY THROUGH FRIDAY, 8AM TO 5PM EST)

DRAWER CONVERSION PANEL / REINFORCEMENT





FIGURE M

4POST HINGED DOORS (HD2)




INSTALL INSTRUCTIONS




4POST HINGED DOORS (HD2)

PLEASE OPEN ALL BOXES AND MAKE SURE THAT YOU HAVE ALL REQUIRED COMPONENTS
READ ALL INSTRUCTIONS BEFORE STARTING ASSEMBLY

INCLUDED HARDWARE





#10-24 FLANGED
HEX NUT (4)
PNUT0052



#10-24 x 3/8
PAN HD PHIL TAPPING (30)
PSCR0190






#10-24 X 5/8"
PAN HEAD PHILLIPS
MACHINE SCREW (4)
PSCR0041




#10 x 1/2"
PAN HD PHIL
TEK SCREW (12)
PSCR0247


COMPONENTS



UPPER FRAME
MOUNTING BRACKET (2)




FRAME SUPPORT
BRACKET (CORNER) (4)



FRAME SUPPORT
BRACKET (SIDES) (4)

4POST HINGED DOORS (HD2)

FIGURE A



STEP 1:

PLACE LOWER FRAME ON FLOOR IN FRONT OF 4POST UNIT AND THEN SLIDE FRAME IN AGAINST SINGLE RIVET SHELF SUPPORT AS SHOWN IN FIGURE A & DETAIL B. IF USING A DOUBLE RIVET SHELF SUPPORT AND KICK PLATE (2" OR 4") SEE FIGURE C & DETAIL D. MAKE SURE LOWER DOOR FRAME IS CENTERED BETWEEN UPRIGHTS, THEN INSTALL (4) #10 x 1/2" PHIL HD TEK SCREWS USING EXISTING HOLES IN LOWER DOOR FRAME AS A GUIDE TO ATTACH FRAME TO SHELF SUPPORT (OR KICK PLATE) AS SHOWN.

DETAIL B






FIGURE C




DETAIL D



4POST HINGED DOORS (HD2)


STEP 2:

INSERT RIGHT UPRIGHT INTO SLOTS ON LOWER FRAME AS SHOWN IN FIGURE E MAKING SURE TO HAVE THE HOLES FOR THE CORNER SUPPORT BRACKETS AND DOOR HINGES ORIENTED AS SHOWN.



STEP 3:

ATTACH UPRIGHT TO LOWER FRAME USING FRAME SUPPORT BRACKET (CORNER) AND (2) #10-24 x 3/8 PAN HD PHIL TAPPING SCREWS AS SHOWN IN FIGURE F.




STEP 4:

REPEAT STEPS 2 & 3 TO ATTACH LEFT UPRIGHT TO LOWER FRAME

4POST HINGED DOORS (HD2)

FIGURE G



STEP 5:

ATTACH UPPER FRAME TO LEFT AND RIGHT UPRIGHTS SIMILAR TO STEPS 2-4 AS SHOWN IN FIGURE G.





FIGURE H


DETAIL J



STEP 6:

SECURE UPPER FRAME TO 4POST UNIT TOP SHELF SUPPORT USING UPPER MOUNTING BRACKETS AND HARDWARE AS SHOWN IN FIGURE H AND DEAIL J.

FIGURE K



NOTE:

WHEN USING HEAVY DUTY TOP SHELF SUPPORT USE OFFSET SIDE OF UPPER MOUNTING BRACKET AS SHOWN IN FIGURE K.




4POST HINGED DOORS (HD2)

CAUTION

4POST UNIT MUST BE SECURED TO WALL.
THE WEIGHT OF THE DOORS MAY CAUSE THE UNIT TO TIP FORWARD IF 4POST UNIT IS NOT PROPERLY SECURED.

STEP 7:





ATTACH DOOR ASSEMBLIES TO VERTICAL UPRIGHTS USING (3) #10-24 x 3/8 PHIL HD TAPPING SCREWS PER HINGE AS SHOWN IN FIGURE L AND DETAIL M.




STEP 8:

ATTACH FRAME SUPPORT BRACKETS (QTY. 4, 2 ON RIGHT SIDE, 2 ON LEFT SIDE) TO ANY 2 SHELF SUPPORTS BETWEEN THE TOP AND BOTTOM OF THE ASSEMBLY. ATTACH WITH (2) #10 x 1/2" PHIL HD TEK SCREWS PER BRACKET AS SHOWN FIGURE L AND DETAIL N.

FRAME SUPPORT BRACKET (SIDES)
MAKE SURE THAT SHELF SUPPORTS ARE IN THE DESIRED POSITION BEFORE INSTALLING ANY SCREWS.






4Post Garment Rack Assembly Instructions



STEP 1

Thread a 1/4-20 hex bolt into each side of the garment tube. Do not fully tighten the bolts. Instead, leave a 1/8" gap between the bolt head & the threaded insert.




DETAIL A


STEP 2

There needs to be a support bracket attached to each corner of the 4Post unit to mount the garment rack. To install the garment rack correctly, support brackets must be level with each other. To attach brackets, simply seat the rivets of the support brackets into the bottom of the upright keyholes. NOTE: Support brackets may need to be installed upside down if a shelf falls right above the garment rod.

STEP 3

Place an L-Bracket over the support brackets. Attach the L-Bracket with #8 x 3/8" tek screws. Repeat for the opposite side.







STEP 4

Place the hex head of one of the bolts into an L-Bracket 1/2" hole. Snap the opposite hex head into the opposite L-Bracket's 1/2" hole.

STEP 5

Slide the tube to the desired slot for your application. If you'd prefer the tube not have adjustability, tighten the (2) 1/4-20 hex head bolts with an open ended wrench.



NOTE

Multiple tubes may be used on the same L-Bracket, depending on their purpose or size. Install the extra tubes following steps 4 & 5.

END OF INSTRUCTIONS.

FOR ASSEMBLY ASSISTANCE CONTACT CUSTOMER SERVICE AT
1-866-217-0330 (MONDAY THROUGH FRIDAY, 8AM TO 5PM EST).